

J-NET ADVANCED-COMS RS 485

CONNECTING JUNO-NET PANEL TO ODYSSEY



IMPORTANT

ON

RS422	RS485
ECHO ON	ECHO OFF
4 WIRE	2 WIRE
4 WIRE	2 WIRE

ALWAYS THIS CONFIGURATION

